

1. OEM RED HAZARD SWITCH STILL INSTALLED



2. CAREFULLY PULL SWITCH TO DETACH



3. CUT A PIECE OF TAPE ABOUT 1/2" IN LENGTH



4. CENTER, AND APPLY THE TAPE EVENLY OVER THE SWITCH



5. INSERT SWITCH COVER USING A SMALL
AMOUNT OF PRESSURE (WIGGLE IT IF IT DOESN'T
SLIP IN EASILY)

SWITCH SHOULD BE SECURELY IN PLACE NOW

REPEAT FOR ALL OTHER SWITCH COVERS



IMPORTANT NOTE: UNDER THE NEW SWITCH COVER IS A SMALL DIMPLE,
MAKE SURE TO ALIGN THAT UP WITH THE SMALL NOTCH ON THE RIGHT SIDE
OF THE BARE SWITCH.



